





Printed from JeppView for Windows 5.3.0.0 on 31 Dec 2023; Terminal chart data cycle 26-2023; Notice: After 04 Jan 2024, 0000Z, this chart may no longer be valid					
LGAV/ATH					
INS COORDS					
STAND No.	COORDINATES	STAND No.	COORDINATES	STAND No.	COORDINATES
APRON NORTH		APRON SOUTH		GA APRON	
B30, B30B B31 B32 B33 B34	N37 56.4 E023 57.2 N37 56.5 E023 57.2 N37 56.4 E023 57.2 N37 56.5 E023 57.2 N37 56.4 E023 57.2	A40 A40A A41 A41A A41B thru A44	N37 55.7 E023 56.5 N37 55.7 E023 56.6 N37 55.7 E023 56.5 N37 55.6 E023 56.5 N37 55.7 E023 56.5	G01, G01A G02 thru G04A G05 thru G07 G08, G09 G10 thru G16A	N37 57.0 E023 57.7 N37 57.0 E023 57.8 N37 57.0 E023 57.7 N37 57.1 E023 57.7 N37 57.0 E023 57.7
B35 B36 B37 B38 B39	N37 56.5 E023 57.2 N37 56.4 E023 57.1 N37 56.5 E023 57.2 N37 56.5 E023 57.1 N37 56.5 E023 57.2	A45 A46, A46A A47, A49 A49A A49B	N37 55.7 E023 56.4 N37 55.8 E023 56.4 N37 55.7 E023 56.4 N37 55.7 E023 56.3 N37 55.7 E023 56.4	G17, G17A G18 thru G20	N37 57.0 E023 57.8 N37 57.1 E023 57.8
B40 thru B43 B44 B45	N37 56.5 E023 57.1 N37 56.5 E023 57.0 N37 56.6 E023 57.1	A50 thru A52 A54 thru A58	N37 55.6 E023 56.4 N37 55.6 E023 56.3	HELIPORT	
COMMUTER APRON		CONTACT STANDS AT MTB		MAIN TERMINAL APRON	
B50 B51 B52 B53 B54 thru B59	N37 56.5 E023 57.3 N37 56.6 E023 57.4 N37 56.6 E023 57.3 N37 56.6 E023 57.4 N37 56.6 E023 57.3	A01 A03, A05 A07 thru A09A A11 thru A13A B03 thru B07	N37 56.1 E023 56.9 N37 56.1 E023 56.8 N37 56.0 E023 56.8 N37 56.0 E023 56.7 N37 56.2 E023 56.9	H01 thru H06 H07, H08 H09 thru H13 H14, H15 H16	N37 56.8 E023 57.4 N37 56.8 E023 57.3 N37 56.7 E023 57.4 N37 56.7 E023 57.3 N37 56.8 E023 57.3
B60 B61 B62 B63 B64	N37 56.6 E023 57.2 N37 56.6 E023 57.3 N37 56.6 E023 57.2 N37 56.7 E023 57.2 N37 56.6 E023 57.2	B09 thru B15	N37 56.3 E023 57.0	Y2 APRON	
B65 B66 B67	N37 56.7 E023 57.2 N37 56.6 E023 57.2 N37 56.7 E023 57.2	CONTACT STANDS AT SATELLITE		B70 thru B72 B73 B74, B76 B78 thru B84	N37 56.7 E023 57.4 N37 56.7 E023 57.5 N37 56.7 E023 57.4 N37 56.7 E023 57.3
CARGO APRON 1		HANGAR/GA APRON			
F02 thru F02H F04 F04A F04B, F04C F04D	N37 55.5 E023 56.3 N37 55.4 E023 56.3 N37 55.5 E023 56.3 N37 55.4 E023 56.3 N37 55.5 E023 56.3	A30 A31 thru A31B A32, A32A A33, A33A A34, A34A	N37 55.8 E023 56.7 N37 55.8 E023 56.6 N37 55.9 E023 56.6 N37 55.8 E023 56.6 N37 55.9 E023 56.6		
F04E thru F04H F06 thru F06B F06C F06D thru F06F F06G, F06H	N37 55.4 E023 56.3 N37 55.4 E023 56.2 N37 55.4 E023 56.3 N37 55.4 E023 56.2 N37 55.4 E023 56.3	A35 thru A35B A36, A36A A37 thru A37B A38, A38A A39, A39A	N37 55.9 E023 56.5 N37 55.9 E023 56.6 N37 55.9 E023 56.5 N37 55.9 E023 56.6 N37 55.9 E023 56.5		
F08 thru F08G F08H, F08I	N37 55.4 E023 56.2 N37 55.3 E023 56.2				
CARGO APRON 2					
F01, F03 F05 F07 F09 thru F09B F11 thru F11B	N37 55.5 E023 56.4 N37 55.6 E023 56.4 N37 55.6 E023 56.3 N37 55.5 E023 56.4 N37 55.5 E023 56.3	C01 thru C03 C04, C05 C06, C07 C08, C09 C10  C50, C51 C52A thru C54 C55 thru C61 C62, C63 C54, C65  C66, C67	N37 56.8 E023 57.7 N37 56.9 E023 57.7 N37 56.9 E023 57.8 N37 57.0 E023 57.8 N37 57.0 E023 57.9  N37 56.9 E023 57.8 N37 57.0 E023 57.8 N37 56.9 E023 57.7 N37 56.9 E023 57.7 N37 56.9 E023 57.8		